


# MANUAL BARRA DE LUCES LED CON DIFUSOR DE AIRE



1. Conecte la manguera con la salida del difusor. (Manguera no incluida).
2. Limpie el acuario y coloque la luz LED en la parte inferior o en la parte trasera del acuario. Consulte la figura inferior.
3. Conecte una válvula antiretorno al tubo para evitar el flujo en retroceso del agua. Consulte los datos expuestos abajo para seleccionar la bomba de aire. La bomba de aire debería colocarse por encima del nivel máximo de agua. (La bomba de aire y la válvula de retención no están incluidas).
4. Enchúfela y utilícela como se muestra en la tabla inferior.

MODELO	COMPRESOR (Salida)
BAR1-BAR5	> 600ml/min
BAR2-BAR6	> 700ml/min
BAR3-BAR7	> 800ml/min



# INSTRUCTIONS LED LIGHT BAR WITH SUBMERSIBLE AIR DIFFUSER



1. Connect the air tube with the outlet of the air stone. (Air tube is not included).
2. Clean the aquarium and place the LED light on the bottom or on the back side of the aquarium. Please refer to the picture below.
3. Connect one check valve to the air tube to prevent the water backflow. Please refer to the data below to select the air pump. The air pump should be placed higher than the maximum water level. (Air pump & check valve are not included).
4. Plug it in and use it as shown in the table below.

MODEL	AIR PUMP (Output)
BAR1-BAR5	> 600ml/min
BAR2-BAR6	> 700ml/min
BAR3-BAR7	> 800ml/min

